

VTT G8X Rear Bushing Insert install guide



Thank you for your purchase of the VTT BMW G8X Rear Bushing insert kit! The first thing to do when you open your box is to make sure all parts are in their respective bags, and nothing has been left out or lost during shipping. Here is a breakdown of what you should have.

- 2 – Bushing Inserts
- 2 – Hardened Large OD Washers
- 1 – 12.9 Grade M14 Bolt
- 1 – M14 Lock Nut



Once all parts are accounted for you can proceed with the Insert Installation. We

suggest this only be done by a qualified technician. If something was missing from your upgrade, please contact us immediately so we can remedy this.

READ THE ENTIRE GUIDE BEFORE BEGINNING INSTALLATION!



ANY QUESTIONS, OR FITMENT PROBLEMS, PLEASE EMAIL SALES@VARGASTURBO.COM BEFORE TRYING TO FORCE OR MODIFY ANYTHING. THIS UPGRADE IS PLUG AND PLAY IF THESE INSTRUCTIONS ARE

**FOLLOWED, ANY ISSUES NEED TO BE ADDRESSED TO
AVOID PROBLEMS**

INSTALL GUIDE

**Please note, this guide is intended to help with the
installation of the Rear Diff Bushing only.**

1. Gain access to the Rear diff bushing by removing any undertrays, exhaust, etc. This guide is for the Bushing kit ONLY, this is not a guide on how to remove or install anything else on the vehicle.
2. Support the diff, and remove the factory Diff Bolt, and nut
3. Lube up the rear bushing insert very well, and line up the tabs on the insert to the bushing, there are small, and large tabs. Once lined up, push in by hand as far as you can.
4. Using the factory bolt, one large washer, and factory nut tighten until the bushing is pressed all the way in.
5. Once all the way in, remove the factory bolt, and nut, install the new bolt with large washer under the head, and washer against the bushing.
6. Tighten the new bolt to factory TQ spec